### SONY

# Sony LiDAR Viewer USB mode User manual

Rev 0.0.1 (draft version)




Sony Semiconductor Solutions Group

### **Outline**

- System overview
- Quick start
  - Quick start (USB connection)
- Sony LiDAR Viewer / View UI
- Sony LiDAR Viewer /Settings
- Sony LiDAR Viewer / File data format

### **Precautions**

- Safety precautions
  - Laser Safety
    - CLASS 1 LASER PROCUCT. The product fulfills the IEC60825-1:2014.



- Mechanical & Electrical Safety
  - This kit is powered by 12V DC and contains a rapidly spinning assembly.

CAUTION - For your safety, do not open the cover.

CAUTION - Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

### **Precautions**


- Set-up precautions
  - Set up the kit away from moving and vibration.
  - Keep the torque as 0.5Nm when fastening the kit with the backside screw hole
  - DO NOT set up the kit near any heat resources.
  - DO NOT disconnect any cable while power ON.
- Others
  - The kit is only aimed for basic evaluation of IMX459's performance and characteristic. Currently it is impossible to obtain real value of internal signals

- HW
  - The LiDAR PoC(SPD-M1) is a mechanical LiDAR kit with Sony's IMX459 SPAD sensor embedded, composed of sensor head unit and control box unit.
- SW
  - "Sony LiDAR Viewer" software is provided for the evaluation of LiDAR PoC(SPD-M1)


### Sensor Head



**Control Box** 




Sony LiDAR Viewer



### HW specification


Model name	SPD-M1	
Measurable distance	10% reflectance : 110 m @100 klux Max : 300 m	
Accuracy	< 15 cm* when not saturated	
Field of View	H120°* V19,2°	
Angular Resolution	H0.2°* V0.2° (H 600 column scan* V 96 dots)	
Frame Rate	10 FPS	
Laser	Class 1- Eye Safe, 905 nm	
Power supply	USB-C PD3.0 or DC12V	
Power Consumption	Sensor Head : 20W (typical) Control Box : 20W (typical)	
Interface	USB3.0 or Ethernet IPv4	
Operation temperature	Ta -20°C ~ +65°C	
Waterproof	Sensor Head : IP66 Control Box : Not supported	
Size	Sensor Head : W158 × D90 × H96 mm Control Box : W124 x D115 x H54 mm	
Weight	Sensor Head : 1.3 kg Control Box : 660 g	

- Sony LiDAR Viewer main functions
  - Supported the following display mode
    - 3D point cloud (viewpoint can be changed)
    - 2D depth/intensity/mixed map
    - 2D ambient light image
  - Supported the following IMX459 operation mode
    - 1 Ranging mode (96pixel mode, 300m, 1GHz sampling, 5Echo)
    - 2 Ranging mode (192pixel mode, 150m, 1GHz sampling, 5Echo)
    - 3 Echo mode (only for data export, 74bin, 2Echo)
    - 4 Hist mode (only for data export, 242bin)
  - Supported multiple LiDAR POC
    - Up to 3 LiDAR POC
  - Supported the following status monitor
    - LiDAR status
    - Temperature, FPS
  - Supported data saving and playback
  - Supported display color change



### Item list

No.	Item	Detail	Note
1	Sensor head	LiDAR PoC module(inc.IMX459).	
2	Control box		
3	FAKRA cable	Communicate between sensor head and control box by MIPI I/F	
4	USB Type-C cable	Supply power to control box	PD3.0
5	4pin power cable	Supply power to sensor head via control box.	
6	Sony LiDAR Viewer	Software	The manual is based on version 8.4











Sensor Head

Control box

FAKRA Cable

Power supply cable

**USB-C** Cable

Additional item list

\*User should prepare following items in advance

No.	Item	Requirement	Note
7	PC	OS: Win 10 CPU: Core i5 or greater Memory: 16G or more	
8	USB PD power adapter	PD3.0 90W (or more)	
9	USB 3.0 cable	TypeA – MicroB 3m or more recommended	Required for USB I/F connection


# **Quick start**

- Sony LiDAR Viewer installation
  - Open the installer: SonyLidarViewer\_r8.4-custom.msi
  - Follow the explanation and finish the installation.
  - Viewer shortcut will be created at Desktop folder









提 Sony LiDAR Viewer Setup

Ready to Install Sony LiDAR Viewer

Click Install to begin the installation. Click Back to review or change any of your installation settings. Click Cancel to exit the wizard.


Back Install Cancel

Cancel


**User Agreement** 

Installation path

Hardware setup




- Turn on the power of the control box
- Check the LED lights up




- Connect the control box with USB3.0 to PC.
- Install the POC (SSP-500) driver. The driver is included below.
  - (Windows10 64bit): installed dir¥driver¥SSP500¥x64 Win10Release
- Confirm the device shows in device manager




- Turn on
  - Execute LidarPocViewer.exe
  - Select [File] → [Device Settings(1 device)] to open "Device Setting" window
  - In the [DEVICE] tab, confirm that [SD] is checked and set to 1 range 96
  - Click [Open] and wait the play starting






- Turn off
  - Close the viewer and turn off the control box
    - Please wait more than 3 seconds before re-turn it ON.

Sony LiDAR Viewer main screen




Automotive Business Division, Sony Semiconductor Solutions Corporation

• Grid in point cloud and eye bird view




- Depth/Intensity/Ambient view
  - The pages describes the layout of 2d view

1 device connected




3 devices connected




- ☐ If multi devices are connected, views will be merged horizontally.
  - Set position at grid position in device setting
  - ☐ Set size at display pixel range in device setting

Mouse + keyboard operation in view windows

### **Point cloud**




### Brid's eye view



■ Left click + drag: Position operation The viewpoint position moves vertically and horizontally \* Direction is fixed ■ Wheel: Zoom in / out

Mouse + keyboard operation in view windows

### 2D mixed/intensity/depth/ map




### **Notice**

For viewer setting, please read p21-36 sequentially.


Automotive Business Division, Sony Semiconductor Solutions Corporation

- Menu
  - File → [Device Settings(1/3 devices)]
  - Choose 1/3 devices with your use-case \*UI shows 3 same windows when 3devices selected.




Copying/Printing Prohibited


- Menu
  - [File] → [Device Settings(1/3 devices)] → [Device]
  - Set in the tab to connect the devices by USB



- Menu
  - [File] → [Device Settings(1/3 devices)] → [View]
  - After Open successfully, system status and further setting will be available at the lower part



- Menu
  - [File] → [Device Settings(1/3 devices)] → [Calc]
  - After Open successfully, system status and further setting will be available at the lower part




CALC_MODE	Description
0(OFF)	Sensor output(Peak position/intensity) will be used directly.
1(MODE1)	Depth and intensity will not be calculated by peak position/intensity directly Calculation is based on FWHM


Menu

• [File] → [Device Settings(1/3 devices)] → [Filter]


• After Open successfully, system status and further setting will be


available at the lower part







- Menu
  - [File] → [Device Settings(1/3 devices)] → [Filter]
  - After Open successfully, system status and further setting will be available at the lower part







- Menu
  - [File] → [Device Settings(1/3 devices)] → [Filter]
  - After Open successfully, system status and further setting will be available at the lower part




- Menu
  - [File] → [Device Settings(1/3 devices)] → [Filter] Filter comparison


1 11001 0011110011	
Filter OFF	
Stray light reduction ON	
Noise reduction ON	
Darkline interpolation ON	
3 Filter ON	

Copying/Printing Prohibited

28


- Menu
  - File → [Device General Settings]
  - Fine-tune angles of the 2D/3D view by click direction button.
  - Refer the details in the window






29


- Menu
  - [File] → [Save Settings] or [Auto Save Settings]
  - [Save Settings]
    - Click it to save settings manually
  - [Auto Save Settings]
    - Check it and settings will be saved automatically after viewer is closed



- Menu
  - [File]  $\rightarrow$  [Capture]
  - 2D view will be captured with .bmp format in installed dir¥bin¥capture folder




- Menu
  - [View]
  - On/off every view element




■ Presentation Mode: Viewer shows in full screen without menu and side bar

- Side bar
  - [Expression]




- Side bar
  - [Color]



- Side bar
  - [Record]
  - Record start. Data will be save in installed dir\u00e4bin\u00e4recored.X (X is the number of port)
  - Record files will be saved in installed dir¥bin¥output
  - Parameter JSON file will also be saved

■ Reference of bin size and current recorded size

■ Current memory statue




- Replay
  - If bin files is loaded in the device setting, use those buttons to play, pause, step forward, etc. Record button is used as home
  - Recording Mode
    - Recoding Time
      - □ Check to record by setting time lenath
      - ☐ Check to record by setting frames number
    - File type
      - Set saved file type. Refer next page
    - In memory
      - Every frame will be saved in memory until record stop to avoid frame dropping
    - Memory size auto
      - □ Check to set memory size automatically for in memory function, otherwise set it manually


### Record file type

File type	Details	Features
BIN	MIPI output of a single frame with header information	The basic format. It can be used as-is for analysis.
BIGBIN	A format that combines multiple BINs into a single file	Even if the number of frames is large, the access overhead to the file system is small.
ZIP	Compressed BIN file in ZIP format	File size can be reduced. Can be compressed and decompressed using standard OS functions.
LZ4BIN	Compressed BIN file in LZ4 format	The CPU load for compression/decompression is very low. The compression ratio is not very high.
ZSTDBIN	Compressed BIN file in ZSTD format	The compression ratio is about the same as ZIP format, and the CPU load is small.

- Side bar
  - [info]
- Manual Selection
  - Check it to set a point manually, or click in 2D view to grab the position automatically
  - Uncheck it to set point automatically. Move mouse cursor inside 2D view to show information automatically



- Menu
  - [File] → [Device Settings(1/3 devices)] → [File]
  - Set in the tab to replay saved bin file



### **Notice**

 For recorded data format, please read p.38-41 sequentially.

 P41-43 describes the data format for ranging mode. Please contact SSS if required data format for Echo/Histogram mode.

### Bin File format

Bin Frame #1 Additional Info

Frame #1 Data

- Bin file stores 1 frame data.
- BigBin file stores multi-frame data in chronological order.
- No explanation here about the compressed file :Zip, LZ4BIN, ZSTDBIN
- 2 major components in bin or BigBin
  - Additional information depending on the file type. See next pages
  - Frame data. See next pages


### BigBin File format

BigBin Frame #1 Additional Info Frame #1 Data BigBin Frame #2 Additional Info Frame #2 Data BigBin Frame #3 Additional Info Frame #3 Data BigBin Frame #4 Additional Info Frame #4 Data BigBin Frame #5 Additional Info Frame #5 Data


The page describes the format of recorded file about the overall structure

File type	Additional info		Frame data
Bin	[Width of frame data] [Height of frame data]	2byte 2byte	Slots
BigBin	[Timestamp] [Width of frame data] [Height of frame data]	8byte 2byte 2byte	Slots


- 1 Frame data is composed of 600 data slots.
- Slot means 1 vertical scanning to read 1 column pixels(default 96).



### Bin File data



### Frame data




The page describes the format of recorded file about the additional info and frame data structure


- The frame data format is based on MIPI output format
- MIPI FS/FE/PH/PF/Blanking will not be saved.
- Every line is composed of 768 Words. If the data is less than 768Words, blanking data will be added at the tail
- Each line (Active area) is composed of 8 pixels
  - In case of vertical 96pixel mode, total active line are 12 lines.
  - In case of vertical 192pixel mode, total active line are 24 lines.
- RAW12 data is padding as 2Bytes.
- Refer application note for more details

Active area (96 pixel mode)



The page describes the format of recorded file about the slot structure






IMX459 MIPI output Format

- Every pixel contains common and echo information with 70 Bytes.
- Refer application note for more details

The page describes the format of recorded file about the active area

### Active area (96 pixel mode)



# **Revision History**

Revision	Date	Remarks
0.0.1	2022/3/18	Draft version

# SONY

SONY is a registered trademark of Sony Group Corporation.

Names of Sony products and services are the registered trademarks and/or trademarks of Sony Group Corporation or its affiliates.

Other company names and product names are registered trademarks and/or trademarks of the respective companies.